XECONO - Economy XBAN Installation

BANNER SIZE:
24" wide by 63" tall

Hub

Legs

Arms

Back Support Leg

1. Banner must have a grommet in each corner and fall within the size range listed above.

2. Open the bottom Legs, Arms and Back Support Leg out and away from the Hub. The Back Support Leg will wedge in place on the back of the Hub.

3. Hang the top grommets of the banner onto the Hooks at the top of the Arms.

4. Pull down the banner and hook the bottom grommets onto the Hooks on the Legs.